



Universal Tool

UT200H Series
Horizontal Grinders
GRINDERS

General Safety Information & Replacement Parts



UT200H-60-6



UT200H-90-CW



UT200H-90-CWE

TABLE OF CONTENTS

General Safety Information	2
Air Compressor and Air Tool Safety	2-3
Tool Specifications	3
Installation	4
Maintenance / Lubrication	4
Operation	5
Troubleshooting	6
Warranty	6
Service Parts	7



WARNING: Risk of injury to persons. Read and understand operation instructions. Always become familiar with all the instructions and warnings before operating any pneumatic tool.

⚠ WARNING

This tool is not suitable for use with Type 1, Type 41 and Type 42 cut off wheels. Do not fit Type 1 or Type 41 or Type 42 wheels to this tool. Using Type 1, Type 41 and Type 42 wheels with this tool can cause serious injury.

⚠ WARNING

Use of threaded hub grinding wheels:

This tool features a 5/8" x 11 TPI unified spindle thread for mounting grinding wheels, along with ANSI standard mounting flanges designed for mounting type 27 grinding wheels. The use of 5/8" x 11 TPI threaded hub grinding wheels as alternatives to type 27 grinding wheels has become more common.

If you intend using threaded hub grinding wheels with this grinder, the following procedures must be followed at all times:

- Before conducting any of the procedures below the grinder must be disconnected from the air supply.*
- 1) The rear wheel mounting flange must be removed from the grinder before use.*
- 2) Once the threaded hub wheel is fitted it must be securely tightened by holding the spindle of the grinder with the wrench provided, while tightening the wheel clockwise with a second wrench placed on the hexagon section at the rear face of the wheel. It is also recommended that for the first operation after fitting the wheel, that the wheel is held firmly on the work surface prior to starting the grinder.*
- 3) Only use threaded hub wheels certified by the manufacturer to meet ANSI B7.1 standards.*

Failure to follow the procedures above can cause injury or death, as deceleration of the grinder may cause the wheel to fly-off; in addition the wheel will not be properly enclosed within the ANSI standard guard supplied with the grinder.



WARNING: This product contains lead, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. **Wash hands after handling.**



WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **Wash hands after handling.**

Safety Information



7.2.2.3 GENERAL SAFETY RULES

- Multiple hazards. Read and understand the safety instructions before installing, operating, repairing, maintaining, changing accessories on, or working near the power tool. Failure to do so can result in serious bodily injury.
- Only qualified and trained operators should install, adjust or use the power tool.
- Do not modify this power tool. Modifications may reduce the effectiveness of safety measures and increase the risks to the operator.
- Do not discard the safety instructions – give them to the operator.
- Do not use a tool if the tool has been damaged.
- Warnings shall be given against the risk of explosion or fire due to the material being processed;
- Warnings shall be given against the risk of cutting.



7.2.2.4 PROJECTILE HAZARDS

- Failure of the work piece, of accessories, or even of the tool itself may generate high velocity projectiles.
- Always wear impact-resistant eye protection during operation of the tool. The grade of protection required should be assessed for each use.



7.2.2.5 ENTANGLEMENT HAZARDS

- Entanglement hazard - choking, scalping and/or lacerations can occur if neck wear, hair or gloves are not kept away from tool and accessories.



7.2.2.7 REPETITIVE MOTIONS HAZARDS

- When using a power tool, you may experience discomfort in your hands, arms, shoulders, neck, or other parts of your body.
- While using a power tool, position your body in a comfortable posture. Maintain secure footing and avoid awkward or off-balanced postures. Changing your posture during extended tasks may help avoid discomfort and fatigue.
- If you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, do not ignore these warning signs. Promptly tell your employer and consult a qualified health professional.



7.2.2.9 WORKPLACE HAZARDS

- Slips, trips and falls are major causes of workplace injury. Be aware of slippery surfaces caused by use of the tool and also of trip hazards caused by the air line or hydraulic hose.
- Proceed with care in unfamiliar surroundings. Hidden hazards may exist, such as electricity or other utility lines.
- This power tool is not intended for use in potentially explosive atmospheres and is not insulated from coming into contact with electric power.
- Make sure there are no electrical cables, gas pipes etc. that could cause a hazard if damaged by use of the tool.



7.2.2.10 DUST AND FUME HAZARDS

- Dust from some work processes can cause cancer, birth defects or other respiratory diseases. Risk assessment of these hazards and implementation of appropriate controls is essential.

- If the pneumatic tool is used in a dust filled environment exhaust air can cause a dust hazard
- Dusts and fumes generated when using power tools can cause ill health (for example: cancer, birth defects, asthma and/or dermatitis); risk assessment of these hazards and implementation of appropriate controls of is essential.
- Risk assessment should include dust created by the use of the tool and the potential for disturbing existing dust.
- Operate and maintain the power tool as recommended in these instructions, to minimize dust or fume emissions
- Direct the exhaust so as to minimized disturbance of dust in a dust filled environment
- Where dusts or fumes are created, the priority shall be to control them at the point of emission.
- All integral features or accessories for the collection, extraction or suppression of airborne dust or fumes should be correctly used and maintained in accordance with the manufacturer's instructions.
- Select, maintain and replace the consumable/inserted tool as recommended in these instructions, to prevent an unnecessary increase in dust or fumes
- Use respiratory protection as instructed by your employer or as required by occupational health and safety regulations;

7.2.2.11 NOISE HAZARDS

- Unprotected exposure to high noise levels can cause permanent, disabling, hearing loss and other problems such as tinnitus (ringing, buzzing, whistling or humming in the ears);
- Risk assessment of these hazards and implementation of appropriate controls of is essential.
- Appropriate controls to reduce the risk may include actions such as damping materials to prevent work pieces from 'ringing'
- Use hearing protection as instructed by your employer or as required by occupational health and safety regulations;
- Operate and maintain the power tool as recommended in these instructions, to prevent an unnecessary increase in noise levels;
- Select, maintain and replace the consumable/inserted tool as recommended in these instructions, to prevent an unnecessary increase in noise.

7.2.2.12 VIBRATION HAZARDS

- Exposure to vibration can cause disabling damage to the nerves and blood supply of the hands and arms;
- Wear warm clothing when working in cold conditions and keep your hands warm and dry;
- If you experience numbness, tingling, pain or whitening of the skin in your fingers or hands, stop using the power tool, and tell your employer. You should also seek medical advice from a qualified occupational health professional.
- Operate and maintain the power tool as recommended in these instructions, to prevent an unnecessary increase in vibration;
- Select, maintain and replace the consumable/inserted tool as recommended in these instructions, to prevent an unnecessary increase in vibration levels;
- Support the weight of the tool in a stand, tensioner or balancer, because the operator can then use a lighter grip to support the tool.
- Hold the tool with a light but safe grip taking account of the required hand reaction forces, because the risk from vibration is generally greater when the grip force is higher.

7.2.3 ADDITIONAL SAFETY INSTRUCTIONS FOR PNEUMATIC POWER TOOLS - AIR SUPPLY & CONNECTION HAZARDS

- Air under pressure can cause severe injury.
- Always shut off air supply, drain hose of air pressure and disconnect tool from air supply when not in use, before changing accessories or when making repairs.
- Never direct air at yourself or anyone else.
- Whipping hoses can cause severe injury. Always check for damaged or loose hoses and fittings.
- Whenever universal twist couplings (claw couplings) are used, lock pins must be installed.
- Do not exceed the maximum air pressure stated on the tool.
- Use whip check safety cables to safeguard against possible hose to tool and hose to hose connection failure.
- Never carry an air tool by the hose.

Safety Information (continued)

AIR COMPRESSOR AND AIR TOOL SAFETY

1. Risk of Bursting. Do not adjust the regulator to result in output pressure greater than the marked maximum pressure of this air tool.
2. Ensure the hose is free of obstructions or snags. Entangled or snarled hoses can cause loss of balance or footing and may become damaged.
3. Never leave a tool unattended with the air hose attached.
4. Do not operate this tool if it does not contain a legible warning label.
5. Do not continue to use a tool or hose that leaks air or does not function properly.
6. Never direct a jet of compressed air toward people or animals.
7. Protect your lungs. Wear a face or dust mask if the operation is dusty.

WARNING: Some dust created by power sanding, sawing, grinding, drilling and other construction activities contains chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:



Lead from lead based paint, crystalline silica from bricks and cement and other masonry products, arsenic and chromium from chemically-treated lumber.

Your risk from those exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well-ventilated area, and work with approved safety equipment, such as dust masks that are specifically designed to filter out microscopic particles.

Important Warnings - Grinders & Cut-Off Tools



1. The stopping time, if longer than 5 seconds, shall be stated, and it shall be recommended to put the grinder in a stable position.
2. When cutting-off, the workpiece shall be so supported that the slot is kept at constant or increasing width during the whole operation.
3. If the abrasive product gets jammed in a cut slot, shut off the grinder and ease the wheel free. Check that the wheel is still correctly secured and not damaged before continuing the operation.
4. Grinding wheels and cut-off wheels shall not be used for side grinding. (Exception: grinding wheels designed for side grinding.) Grinders should not be used over the maximum rated speed of an abrasive product.
5. The operator shall pay attention that no bystanders are in the vicinity.
6. The personal protective equipment such as gloves, apron and helmet shall be used.
7. Never operate the grinder without the original guard supplied by the grinder manufacturer correctly fitted to the grinder.
8. Only use the wheel mounting flanges supplied by the grinder manufacturer.
9. Only use grinding wheels and cut-off wheels and wire brushes that meet ANSI standards, ISO standards or both-this will be shown on the wheel manufacturers label.
10. Only use grinding wheels and cut-off wheels and wire brushes that have the correct center mounting hole or correct threaded insert center to match the spindle thread on the grinder.
11. Never adjust the grinder, adjust the guard or change the wheel unless the air supply and air hose is disconnected from the grinder.
12. Only personnel trained in the correct methods to adjust guards and change grinding wheels or cut-off wheels or wire brushes should conduct these operations.
13. Always ensure that you are aware of the direction of the sparks being created by the grinding operation and ensure that the sparks are not directed to the operator or other persons in the area.
14. Never use a grinder close to any explosive or flammable materials or air conditions.
15. Only use the type of wheel that the grinder manufacturer specifies that the grinder is designed for use with.
16. Never attempt to modify or adapt a grinder or cut-off tool to accept a grinding wheel or cut-off wheel or wire brush that the grinder was not designed for use with.
17. Eye protection, hearing protection, safety gloves and safety aprons must always be worn when operating a grinder

Specifications

UT200H-60-6	UT200H-90-CW	UT200H-90-CWE
Vibration Level (m/sec2): 1.9	Vibration Level (m/sec2): 2.1	
Noise Level (dBA): 89		Noise Level (dBA): 89

Model	Motor (HP)	Motor (kW)	Max. Wheel Dia. (in)	Speed (RPM)	Exhaust	Spindle Size	Guard Type	Weight (lb)	Weight (Kg)	Length (in)	Length (mm)	Rec. Pressure	Air Inlet (NPT)	Rec. Hose (I.D. in)	Air Cons (cfm)	Av. Air Cons (cfm)
UT200H-60-6	2.0	1.47	6" Type 1	6,000	Side	5/8"-11	Type 1	14.08	6.4	19.5	495	90 psi-6.2 bar	1/2"	1/2"	40	10
UT200H-90-CW	2.0	1.47	3" Cone	9,000	Side	5/8"-11	NA	8.20	3.7	17.5	445	90 psi-6.2 bar	1/2"	1/2"	40	10
UT200H-90-CWE	2.0	1.47	3" Cone	9,000	Side	5/8"-11	NA	11.90	5.4	26	660	90 psi-6.2 bar	1/2"	1/2"	40	10


Installation

1 Cleaning the air hose

- A 3/8" air hose is required, with a maximum length of 25 ft.
- Clean the air hose of accumulated dust and moisture before connecting it to the air supply.




NOTE: If a longer air hose is required, connect a 1/2" air hose to the 3/8" air hose to ensure the grinder has the necessary air supply.



Recommended Air Line Set-Up

Part	Description
A	Air Tool
B	Quick Plug
C	Quick Coupler
D	Air Hose
E	In-line Regulator
F	In-line Lubricator
G	In-line Filter
H	Air Compressor



Maintenance

Ensure the air line is shut-off and drained of air before removing this tool for service or changing sockets. This will prevent the tool from operating if the throttle is accidentally engaged.


LUBRICATION

- An in-line filter-regulator-lubricator is recommended as it increases tool life and keeps the tool in sustained operation.
- Regularly check and fill the in-line lubricator with air tool oil. Avoid using excessive amounts of oil.
- Adjust the in-line lubricator by placing a sheet of paper next to the tool's exhaust ports and holding the throttle open approximately 30 seconds. The lubricator is properly set when a light stain of oil collects on the paper.
- If it is necessary to store the tool for an extended period of time (overnight, weekend, etc.), generously lubricate the tool through the air inlet. Run the tool for approximately 30 seconds to ensure the oil is evenly distributed throughout the tool. Store the tool in a clean and dry environment.
- Recommended lubricants: Air tool oil or any other high grade turbine oil containing moisture absorbent, rust inhibitors, metal wetting agents, and an EP (extreme pressure) additive.

Operation


1 Operating the horizontal grinder

- This Horizontal Grinder is designed to operate on 90 PSIG. Lower pressure (below 90 PSIG) will reduce performance of the tool. Higher air pressure (over 90 PSIG) raises the performance of the tool beyond its rated capacity and could cause serious damage to the tool and the user.
- This tool features a safety lock-off mechanism.




3 Install / remove the grinding wheel

- Remove the flange nut with the spanner wrench.
- Install the grinding wheel.
- Replace the flange nut and tighten.



- Remove the flange nut with the spanner wrench.
- Remove the grinding wheel.
- Replace the flange nut and tighten.




2 Install /remove cone wheel




WARNING: Disconnect the tool from the air supply before servicing or changing accessories.

- To install cone wheel, turn clockwise onto the threaded spindle.



- To remove cone wheel, turn counter-clockwise to remove cone wheel.



4 Grinding and deburring




WARNING: You must wear the ANSI approved eye protection during the operation; failure to follow this may result in serious injury or damage to the operator.



WARNING: Hearing protection is strongly recommended. A protective respirator is recommended.

- Connect the grinder to the air supply.
- This tool features a safety lock-off mechanism.
- Operate the tool by disengaging the safety lock-off mechanism and depressing the throttle lever to run the tool for grinding or deburring.



Troubleshooting

Problem	Possible Cause	Solution
The tool runs slowly or will not operate.	There is grit or gum in the tool.	<input type="checkbox"/> Flush the tool with air tool oil or gum solvent.
	The tool is out of oil.	<input type="checkbox"/> Lubricate the tool according to the lubrication instructions in this manual.
	The air pressure is low.	<input type="checkbox"/> Adjust the regulator on the tool to the maximum setting. <input type="checkbox"/> Adjust the compressor regulator to the tool's maximum setting of 90 psi.
	The air hose leaks.	<input type="checkbox"/> Tighten and seal the hose fittings with pipe thread tape if leaks are found.
	The air pressure drops.	<input type="checkbox"/> Ensure the hose is the proper size. Long hoses or tools using large volumes of air may require a hose with an I.D. of 1/2" or larger depending on the total length of the hose. <input type="checkbox"/> Do not use a multiple number of hoses connected together with a quick connect fitting. This causes additional pressure drops and reduces the tool power. Directly connect the hoses together.
	There is a worn rotor blade in the motor.	<input type="checkbox"/> Replace the rotor blade.
	There is a worn ball bearing in the motor.	<input type="checkbox"/> Remove and inspect the bearing for rust, dirt, and grit. Replace or clean and grease the bearing with bearing grease.
	There is moisture blowing out of the tool's exhaust.	<input type="checkbox"/> Drain the tank. (See the air compressor manual for instructions.) Lubricate the tool and run it until water is not evident. Lubricate the tool again and run for 1-2 seconds.


Warranty

Limited Warranty: Universal Tool warrants its tools to be free from defects in material and workmanship for one year from the date of purchase. This warranty does not apply to tools which have been abused, misused, modified or repaired by someone other than Universal Tool or its authorized service centers. If a UT tool proves defective in material or workmanship within one year after purchase, return it to any authorized service center or Universal Tool freight prepaid. Please enclose your name, address and adequate proof of date of purchase and a short description of the defect. Universal Tool will, at its option, repair or replace defective tools free of charge. Repairs or replacements are warranted as described above for the remainder of the original warranty period. Universal Tool's sole liability and your exclusive remedy under this warranty is limited to repair or replacement of the defective tool.

There are no other warranties expressed or implied and Universal Tool shall not be liable for incidental, consequential or special damages, or any other damages, costs or expenses excepting only the cost or expense of repair or replacement as described above.


Service Parts / Exploded View Drawing

UT200H-90-CW




Ref #	Part Number	Description	Qty
1	9200H6001	BOLT	1
2	988005	O-RING	1
3	9200H6003	SPRING	1
4	9200H6004	VALVE	1
5	9OB-04	O-RING	1
6	9200H6006	OIL PIPE	1
7	9200H6007	BUSHING	1
8	9200H6008	AIR INLET	1
9	9200H6009	O-RING	1
10	9200H6010	WASHER	1
11	9200H6011	PIN	1
12	9OB-11.1	O-RING	1
13	9200H6013	HOUSING HANDLE	1
14	980528	SCREW	1
15	9200H6015	PIN	1
16	9200H6016	LEVER	1
17	987020	SPRING HOLDER	1
18	987021	WASHER	1
19	987022	SPRING	1
20	987023	GOVERNOR VALVE	1
21	987024	PIN	1
22	987026	GOVERNOR PIN	2
23	987025	GOVERNOR WEIGHT	2
24	987027	GOVERNOR CAGE	1
25	987028	WASHER	1
26	987029	BEARING	1
28	987030	REAR PLATE	1

Ref #	Part Number	Description	Qty
29	987031	ROTOR BLADE	4
30	9200H6030	ROTOR	1
31	987034	CYLINDER	1
32	981326	PIN	2
33	9200H6033	WASHER	1
34	9200H6034	FRONT PLATE	1
35	9200H6035	BEARING	1
36	9200H6036	NUT	1
37	9200H6037	COUPLING	1
38	970048A	BEARING	2
39	9200H9039	SHAFT	1
40	9200H6040	SLIDING KEY	1
41	9200H6041	HOUSING	1
42	9200H6042	O-RING	1
43	9200H6043	MUFFLER BODY	1
44	9STOB-24	O-RING	1
45	9200H6045	SNAP RING	1
46	9200H6046	BUSHING	1
47	9200H6047	BEARING	1
48	9200H6048	WASHER	1
49	9200H6049	WASHER	1
50	9200H6050	BOLT	1
54	9200H6054	O-RING	1
55	9200H6055	O-RING	1
59	9200H9059	DISC NUT	1
60	9200H9060	SCREW	1
61	9200H9061	SPANNER	1
62	9200H6062	O-RINGS	2



Ref #	Part Number	Description	Qty
1	9200H6001	BOLT	1
2	988005	O-RING	1
3	9200H6003	SPRING	1
4	9200H6004	VALVE 9EM	1
5	9OB-04	O-RING	1
6	9200H6006	OIL PIPE	1
7	9200H6007	BUSHING	1
8	9200H6008	AIR INLET	1
9	9200H6009	O-RING	1
10	9200H6010	WASHER	1
11	9200H6011	PIN	1
12	9OB-11.1	O-RING	1
13	9200H6013	HOUSING HANDLE	1
14	980528	SCREW	1
15	9200H6015	PIN	1
16	9200H6016	LEVER	1
17	987020	SPRING HOLDER	1
18	987021	WASHER	1
19	987022	SPRING	1
20	987023	GOVERNOR VALVE	1
21	987024	PIN	1
22	987026	GOVERNOR PIN	2
23	987025	GOVERNOR WEIGHT	2
24	987027	GOVERNOR CAGE	1
25	987028	WASHER	1
26	987029	BEARING	1
28	987030	REAR PLATE	1
29	987031	ROTOR BLADE	4

Ref #	Part Number	Description	Qty
30	9200H6030	ROTOR	1
31	987034	CYLINDER	1
32	981326	PIN	2
33	9200H6033	WASHER	1
34	9200H6034	FRONT PLATE	1
35	9200H6035	BEARING	1
36	9200H6036	NUT	1
37	9200H6037	COUPLING	1
38	970048A	BEARING	2
39	9200H9039	SHAFT	1
40	9200H6040	SLIDING KEY	1
41	9200H6041	HOUSING	1
42	9200H6042	O-RING	1
43	9200H6043	MUFFLER BODY	1
44	9STOB-24	O-RING	1
45	9200H6045	SNAP RING	1
46	9200H6046	BUSHING	1
47	9200H6047	BEARING	1
48	9200H6048	WASHER	1
49	9200H6049	WASHER	1
50	9200H6050	BOLT	1
54	9200H6054	O-RING	1
55	9200H6055	O-RING	1
59	9200H9059	DISC NUT	1
60	9200H9060	SCREW	1
61	9200H9061	SPANNER	1
62	9200H6062	O-RINGS	2
63	9200H90E63	SPINDLE HOUSING	1



Ref #	Part Number	Description	Qty
1	9200H6001	BOLT	1
2	988005	O-RING	1
3	9200H6003	SPRING	1
4	9200H6004	VALVE STEM	1
5	90B-04	O-RING	1
6	9200H6006	OIL PIPE	1
7	9200H6007	BUSHING	1
8	9200H6008	AIR INLET	1
9	9200H6009	O-RING	1
10	9200H6010	WASHER	1
11	9200H6011	PIN	1
12	90B-11.1	O-RING	2
13	9200H6013	HOUSING HANDLE	1
14	980528	SCREW	1
15	9200H6015	PIN	1
16	9200H6016	LEVER	1
17	987020	SPRING HOLDER	1
18	987021	WASHER	1
19	987022	SPRING	1
20	987023	GOVERNOR VALVE	1
21	987024	PIN	1
22	987026	GOVERNOR PIN	2
23	987025	GOVERNOR WEIGHT	2
24	987027	GOVERNOR CAGE	1
25	987028	WASHER	1
26	987029	BEARING	1
28	987030	REAR PLATE	1
29	987031	ROTOR BLADE	4
30	9200H6030	ROTOR	1

Ref #	Part Number	Description	Qty
31	987034	CYLINDER	1
32	981326	PIN	2
33	9200H6033	WASHER	1
34	9200H6034	FRONT PLATE	1
35	9200H6035	BEARING	1
36	9200H6036	NUT	1
37	9200H6037	COUPLING	1
38	970048B	BEARING	2
39	9200H6039	SHAFT	1
40	9200H6040	SLIDING KEY	1
41	9200H6041	HOUSING	1
42	9200H6042	O-RING	1
43	9200H6043	MUFFLER BODY	1
44	9STOB-24	O-RING	1
45	9200H6045	SNAP RING	1
46	9200H6046	BUSHING	1
47	9200H6047A	BEARING	1
48	9200H6048	WASHER	1
49	9200H6049	DUSTPROOF WASHER	1
50	9200H6050	BOLT	1
51	9200H6051	DISC NUT	1
52	9200H6052	DISC NUT	1
53	9200H6053	NUT	1
54	9200H6054	O-RING	1
55	9200H6055	O-RING	1
56	9200H6056	SPANNER	1
57	9200H6057	SPANNER	1
58	9200H6058	DISC COVER	1
62	9200H6062	O-RING	2



Universal Tool

Questions, problems, missing parts?

Call Customer Service
8 a.m.-5 p.m., EST, Monday-Friday

1-800-356-3392

FLORIDA-PNEUMATIC.COM

Retain this manual for future use.